COOKTOP PARTS

For Model: RF110AXSQ3
(Designer White)

30" ELECTRIC FREESTANDING
STANDARD CLEAN RANGE



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10141166	Instructions, Installation
	9763000	Owners Manual
	W10114281	Sheet, Tech
	9762761	Safer Cooking Tips Template,Anti−Tip
	9757142	English/Spanish
	9757143	English/French
2		Bowl, Drip
	3195208	6" Chrome (3)
	3195209	8" Chrome (1)
3		Cooktop
	3186235	White
4	3195060	Hinge, Cooktop (2)
5	3196178	Screw
6	308605	Strain Relief
7	3195812	Rod, Support (2)
9	814399	Receptacle, Elmnt
10	3196154	Screw
11		Element, Surface
	9761348	6" (3)
	9761346	8" (1)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Model: RF110AXSQ3
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1		Endcap
	W10009040	Left Hand White
	W10009050	Right Hand White
2	9757609	Nameplate
3		Panel, Backguard
	W10170674	White
4		Switch, Infinite
	3148953	Use W/ 8" Element
	3148951	Use W/ 6" Element
5	8523265	Indicator, 125V
6	9762215	Cntrl−Elec ROC60
7	W10182322	Brkt−Mntg,Console
8	8523266	Indicator, 250V
9	3196166	Screw
10	3196200	Clip, Spring (2)
11		Knob (4)
	9761962	White
12	3196068	Lens, Ind. (2)
13		Knob, Thermostat
	9762526	White
14	8053912	Shield, Heat
15	8272473	Cover, Upper Rear
16	3196178	Screw
17	3400882	Screw
18	8273564	Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Model: RF110AXSQ3
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Model: RF110AXSQ3
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	3169143	Vent Tube
2	3186144	Box, Burner
3		Panel, Side (2)
	8053830	White−Textured
4	W10129032	Seal, Oven Door
5	9757340	Element, Broil
6	9758541	Element, Bake
7	W10031780	Screw
8	9760407	Brkt, Mounting
9	W10114344	Glide, Drawer Frnt
10	3196037	Foot, Front (2)
11	W10067840	Screw
12	8054068	Tray, Insulation
13	3196576	Clip, Panel (6)
14	9760314	Rail, Base (2)
15	W10058460	Foot, Rear (2)
16	3195809	Bumper, Side (2)
17	3186116	Support, Oven (2)
18	3186034	Bracket, Service
19	9761958	Block, Terminal
	112432	Nut (3)
20	8274034	Back, Main
21	9758283	Cover, Box
22	3196567	Screw
23	3196168	Screw
24	3196174	Screw
25	3196165	Screw
26	3196179	Screw
27	3196178	Screw
28	3400016	Screw
29	W10181986	Sensor
30	3196169	Screw

INSULATION

8273263	Insulation, Wrap
8272611	Insulation, Back

DRAWER & BROILER PARTS

For Model: RF110AXSQ3
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	W10138079	Rack, Oven (2)
2	9761031	Drawer, Storage
3	W10174396	Bracket, Drawer(2)
4		Rivet, Push (2)
	3196814	White
5		Panel, Drawer Frnt
	8053339	White
6	8053334	Glide, Drawer (2)
7	3196168	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Model: RF110AXSQ3
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	W10031790	Screw
2	9761342	Liner
3	8272618	Insulation, Door
4	W10031780	Screw
5	9761495	Hinge (2)
6	3196163	Screw
7		Panel, Steel
	3195560	White
8		Spacer, Handle
	3196143	White
9		Handle, Oven Door
	3195263	White
10		Screw, Top
	3196558	White
11	9761504	Brkt−Door
12	9761517	Clip−Door, Mntg
13	3196165	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Model: RF110AXSQ3
(Designer White)

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated

SPLICING WIRES−−25FT. LENGTH

242828	Wire, Black 12 Ga. 150° c
8316781	Wire, Black 14 Ga. 150°c
242821	Wire, Blue 14 Ga. 150°c
242822	Wire, Brown 14 Ga. 150°c
242830	Wire, Brown 14 Ga. 200°c
242823	Wire, Green 14 Ga. 150°c
242824	Wire, Orange 14 Ga. 150°c
242825	Wire, Red 14 Ga. 150°c
242831	Wire, Red 14 Ga. 200°c
242827	Wire, Yellow 14 Ga. 150°c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch−Up Self−Clean(1/2 Pt)
261582	Grease

INSULATION

261514	Insulation, Fiberglass (1−1/2" x 24" x 120")
240132	Insulation, Fiberglass (2−1/2" x 22" x 120")

PAINT, TOUCH−UP (1/2oz.)

72017	White
4392899	Biscuit
511873	White Porcelain (2 Oz.)

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Almond (Uncut)

ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')
3184478	Cleaner, Glass
4396923	Pan−Broiler

ANTI−TIP KIT

W10017440	Anti−Tip Kit

WIRING HARNESS PARTS

W10113076	Harness, Main
9761476	Harness, Cooktop
3196154	Screw, Grnd−Cktop
3196174	Screw, Grnd−Back
311227	Wire, Ground
313660	Clip, Ground Wire
3196173	Screw, Ground